

W NEKEEPER

NAPA 2x2

Drip Tray Installation Instructions

Unplug the electrical cord from outlet and remove wine from the right side.

Use a 7/16" drill bit. Inside the refrigerator near the thermometer, there is a white tube that runs into the plastic liner. 1" away and directly in front of the white tube is where you need to drill.

Most likely the drill with the bit attached will not fit perfectly vertical. When you start to drill, just drill through the plastic. Once you have a hole in the plastic, without the drill spinning, push the drill into the hole and into the foam insulation. Make sure you are not hitting any other tubing in the insulation. Slowly spin the drill to gently clear out the foam insulation from the hole.

Install a rubber grommet into the new hole in the plastic liner.

The white drip tray should have a clear tube leading off the bottom, and a small metal rod at the end. Feed the metal rod through the grommet, insulation, and sheet metal like a needle. You should be able to see the metal rod hanging from the backside of the unit. Pull the rest of the tubing through, leaving slack.

On the white drip tray, remove the protective backing on the foam tape, and stick the drip tray to the bottom of the first channel above the thermometer. Pull the tube snag.

Use the black plastic evaporation tray to mark the rear of the unit where to drill two or more 7/16th holes. They must be just deep enough to get through the thin sheet metal, centering the evaporation tray above the black compressor motor. Clean off any burrs, and install rubber grommets.

On the clear tubing, remove the metal rod and feed the tubing into the hole provided on the back evaporation tray. Push the tray into place, and pull clear tubing tight so it will not snag.

CONTACT WINEKEEPER

531 Mercantile Drive, Cotati, CA 94931

1.855.511.5113 info@winekeeper.com www.winekeeper.com